

HYDRASleeve™ *Simple by Design.*

SPEEDBAG

Eliminate the wait!

IMPORTANT

SpeedBags require activation of the check valve and oscillation during recovery:

When retrieving the SpeedBag, pull up hard 1-2 feet to open the check valve; let the assembly drop back down to the starting point; **REPEAT THIS PROCESS 4 TIMES; and then quickly recover the SpeedBag through the well screen to the surface.**

Fits 2-inch Sch 40 wells and larger

U.S. Patents No. 6,481,300 and 6,837,120 Other patents pending



1-800-996-2225

2007 Glass Road Las Cruces, NM 88005 | Fax: 575-523-0789 hydrasleeve.com