

Assembly Instructions for NEW 1-inch Skinny HydraSleeve

1. Insert the top (open end) of the HydraSleeve into the female end of the PVC Collar and pull it through.



2. Insert the male threads of the top portion of the PVC Collar into the HydraSleeve. Do not insert the threads past the weld line in the HydraSleeve. NOTE some of the male threads will remain exposed, they will not be threaded entirely into the female portion.



3. GENTLY thread the two portions of the collar together with the HydraSleeve in place between the threads. It only takes a turn or two to hold it in place, DO NOT FORCE THE THREADS.



4. Attach a clip to the holes in the top portion of the PVC Collar as seen here.



5. Insert another clip into the hole at the bottom of the HydraSleeve, under the knot. Then attach an 8-ounce bullet weight to the bottom clip.



When resting on the bottom of the well, the collection cycle will begin ~54 inches off the bottom. It will fill within a 10-foot saturated screen using a single pull stroke. For screens that are less than 10-feet, the unit can be oscillated up and down to allow it to fill. The NEW 1-inch SkinnySleeve holds 300 mls.

THIS SIZE SKINNYSLEEVE FITS IN 1-INCH SCHEDULE 40 WELLS